



MOTORE: LDW 245 JMT - TAVOLA: A

JMT 245  
Tav. A




MOTORE: LDW 245 JMT - TAVOLA: B

JMT 245  
Tav. B




MOTORE: LDW 245 JMT - TAVOLA: C

JMT 245  
Tav. C




**MOTORE: LDW 245 JMT - TAVOLA: D**

**JMT 245  
Tav. D**




**MOTORE: LDW 245 JMT - TAVOLA: E**

**JMT 245  
Tav. E**




MOTORE: LDW 245 JMT - TAVOLA: F

JMT 245  
Tav. F




MOTORE: LDW 245 JMT - TAVOLA: G

JMT 245  
Tav. G




MOTORE: LDW 245 JMT - TAVOLA: H

JMT 245  
Tav. H



MOTORE: LDW 245 JMT - TAVOLA: I-a

JMT 245  
Tav. I-a  
(Euro 3)




MOTORE: LDW 245 JMT - TAVOLA: I-b

JMT 245

Tav. I-b


(Euro 4)



MOTORE: LDW 245 JMT - TAVOLA: L


JMT 245

Tav. L




MOTORE: LDW 245 JMT - TAVOLA: M

JMT 245  
Tav. M




MOTORE: LDW 245 JMT - TAVOLA: N-a

JMT 245  
Tav. N-a



MOTORE: LDW 245 JMT - TAVOLA: N-b


JMT 245  
Tav.N-b



MOTORE: LDW 245 JMT - TAVOLA: N-c

JMT 245  
Tav.N-c


Euro 4






MOTORE: LDW 245 JMT - TAVOLA: O

JMT 245  
Tav. O



MOTORE: LDW 245 JMT - TAVOLA: P

JMT 245  
Tav. P



MOTORE: LDW 245 JMT - TAVOLA: Q

JMT 245  
Tav. Q

